

## SCREEN SHOT FROM DIP SPIN CONTROL CENTER

displayed on this screen. Various parameters of the running cycle and some animation are

displayed on the oven or conveyors. The trays on the Dump/Return conveyor are for tray number reference only. No tray information is available when the tray is on this conveyor. To display tray information, select any one of the numbered trays station prior to the tray dumping or returning for an additional coat. oven on a regular timed interval. The trays are again identified at the at the station located at the entrance to the oven and moved through the numbers are displayed on the screen in an approximate location of where they are located on the oven conveyors. The trays are identified Each tray on the oven conveyors has a unique tray number. The tray

6.) TRAY/PARTS COOLER

7.) TRAY RETURN CONVEYOR

8.) BI-DIRECTIONAL TRANSFER CONVEYOR

9.) FINISHED PRODUCT TRAY DUMPER

10.) SUBSEQUENT COAT SKIP HOIST TRAY DUMPER

11.) SUBSEQUENT COAT PARTS FEED CONVEYOR

batch and queue for subsequent coats. lurnkey coat and cure system eliminates

